4.2 samba服务器配置及使用

@宅学部落 专注嵌入式在线培训



QQ群: 475504428

安装samba服务


- 安装
 - apt-get install samba smbfs
- 创建共享目录
 - mkdir /opt/share
 - chmod 777 /opt/share
- 修改samba配置文件
 - vi /etc/samba/smb.conf

```
[share]
path = /opt/share
available = yes
browseable = yes
public = yes
writable = yes
```

- 创建samba账户
 - touch /etc/samba/smbpasswd
 - smbpasswd—a wit

使用samba服务

- 重启samba服务器
 - /etc/init.d/samba restart
- 从Windows访问并设置网络映射





- 从Linux访问并挂载
 - mount -t smbfs -o username=wit, passwd=123456 //192.168.21.153/share /mnt